# /inritsu

# Site Master™ S331D/S332D

Cable and Antenna Analyzer, 2 MHz to 6 GHz Spectrum Analyzer, 100 kHz to 3 GHz



## Cost Savings and Quality Improvement

Wireless market competition requires operators to reduce per site maintenance expense. Site Master's Frequency Domain Reflectometry (FDR) techniques break away from the traditional fix-after-failure maintenance process by finding small, hard to identify problems before major failures occur.

Sixty to eighty percent of a typical cell site's problems are caused by problematic cables, connectors and antennas. When cables or antennas are contaminated with moisture, damaged, or mispositioned during storms, Site Master identifies the problem quickly. Antenna degradation reduces the cell coverage pattern and can cause dropped calls. Site Master can pinpoint the antenna problem from ground level in a few seconds making climbing the antenna tower unnecessary.

A poorly installed weather seal will corrode connectors and, if undetected, will eventually damage an expensive coaxial cable. Site Master has the sensitivity to identify the connector problem before the cable is damaged. Distance-To-Fault provides the clearest indication of troubled areas. Site Master Revolutionizes Cable and Antenna Sweeping in the Wireless Industry.




PR — RL1

# Rugged and Reliable


Because the Site Master was designed specifically for field environments, it can easily withstand the day-to-day punishment of field use. The analyzer is almost impervious to the bumps and bangs typically encountered by portable field-equipment.

## Easy-to-Use

Site Master operation is straightforward; measurements are obtained through a menu-driven user interface that is easy to use and requires little training. The large, and high-resolution TFT color display makes test interpretation easy and quick. A full range of markers enable the user to make accurate measurements. Limit lines simplify measurements allowing users to create quick and simple pass/fail tests.



Features local language graphical user interface support in English, Chinese, Japanese, French, German, and Spanish.



Save and Recall Display Up to 300 memory locations. Alphanumeric data labeling and automatic time/date stamp simplify data management. AM/FM Receiver with Internal Speaker

Built-in AM/FM demodulator enables testing and trouble-shooting of wireless communications systems. An internal speaker and jack are included.


Function	Benefits
Cable and Antenna Analyzer (S331D/S332D)	Characterize antenna system and pinpoint location of faults
Spectrum Analyzer (S332D)	Easily locate, identify and record various signals with high accuracy
AM/FM Demodulator (S332D)	Built-in demodulator for AM, narrow band FM, wide band FM, and SSB allows technician to listen to and identify interfering signals
Standard TFT Color Display (S331D/S332D)	Display is viewable in direct sunlight
Power Monitor (S331D/S332D)	Performs accurate broadband power measurements using an external detector
High Accuracy Power Meter (S331D/S332D)	Performs accurate RMS power measurements for both CW and modulated signals
Power Meter (S331D/S332D)	Performs accurate power measurements up to 3 GHz without the need of an external detector
Frequency Converter Interface (S332D)	Make measurement from 4.7 GHz to 6 GHz using an external detector
2 MHz and 6 GHz Frequency Extensions (S331D/ S332D)	Extend the lower and upper frequency ranges of the cable and antenna analyzer to 2 MHz and 6 GHz for optimum frequency coverage
Built-in +12V to +24V variable Bias Tee (S332D)	No need to use external power to bias an amplifier
Transmission Measurement (S332D)	Perform a 2-port measurement and measure the insertion gain, loss, and isolation of Tower Mounted Amplifiers, filters, attenuators, and antennas
Interference Analyzer (S332D)	Identify and locate interfering signals that cause dropped calls and coverage problems. Intermittent problems can be identified using spectrograms
Channel Scanner (S332D)	Measure frequency, bandwidth and power of multiple transmitted signals
CW Signal Generator (S332D)	CW source to test low noise amplifiers, repeaters, and BTS receivers
GPS Receiver (S331D/S332D)	Provides location (latitude, longitude, altitude) and UTC time information
T1/E1 Analyzer (S331D)	Simplifies the task of determining if the source of problems is on the wireline or the wireless side

## FDR Technique

Frequency Domain Reflectometry, (FDR), and Time Domain Reflectometry, (TDR), have similar acronyms, and both techniques are used to test transmission lines. But, that's where the similarities end. TDRs are not sensitive to RF problems: the TDR stimulus is a DC pulse, not RF. Thus, TDRs are unable to detect system faults that often lead to system failures. Additionally, FDR techniques save costly, time-consuming trouble shooting efforts by testing cable feed-line and antenna systems at their proper operating frequency. Deficient connectors, lightning arrestors, cables, jumpers, or antennas are replaced before call quality is compromised.

## Quick, Simple Measurements

Site Master performs various RF measurements aimed at simplifying cable feedline and antenna analysis: Return Loss, SWR, Cable Loss and Distance-to-Fault (DTF). A single key selection on the main menu activates the desired measurement mode.





## Return Loss, SWR

Return Loss and SWR "system" measurements ensure conformance to system performance engineering specifications. Measurement easily toggles between either one of the two modes and can be performed without climbing the tower.

## Cable Loss

Cable Loss measurements measure the level of insertion loss within the cable feed-line system. Insertion loss can be verified prior to deployment, when you have access to both ends of the cable, or on installed cables without access to the opposite end. Site Master automatically calculates and displays the average cable loss so there is no more guess work or a need to perform calculations in the field.





## Distance-to-Fault

Although a Return Loss test can tell users the magnitude of signal reflections, it cannot tell the precise location of a fault within the feed-line system. Distance-To-Fault measurements provide the clearest indication of trouble areas as it tells us both the magnitude of signal reflection and the location of the signal anomaly.

Distance-To-Fault measurement capability is built into all Site Master models as a standard feature. Return Loss (SWR) measurement data is processed using Fast Fourier Transform and the resulting data indicates Return Loss (SWR) versus distance. Distance-to-Fault measurements indicating Return Loss or SWR versus time is available with Handheld Software Tools<sup>™</sup>.

# 2 MHz Frequency Extension (Option 2, S331D/S332D)

The standard Site Master spans 25 MHz to 4000 MHz. Option 2 extends the lower frequency range of the cable and antenna analyzer to 2 MHz.

# 6 GHz Frequency Extension (Option 16, S331D/S332D)

Option 16 extends the standard 25 MHz to 4000 MHz frequency range of the cable and antenna analyzer to 25 MHz to 6000 MHz. Option 16 used in conjunction with option 2 provides continuous coverage of the cable and antenna analyzer from 2 MHz to 6 GHz.

## **OSL** Calibration


Open-Short-Load (OSL) calibration is standard for the S331D and S332D. All errors from source match, directivity and frequency response are mathematically removed allowing for accurate vector corrected Return Loss, Cable Loss, VSWR, and DTF measurements. Directivity is usually the main contributor to measurement uncertainty, and corrected directivity of 42 dB or better is common using Anritsu's precision components.

## FlexCal<sup>™</sup>

The Site Master FlexCal<sup>™</sup> broadband calibration feature is an OSL-based calibration method. It offers field technicians a simple and convenient way to troubleshoot and identify faulty antenna system components, because it eliminates the need for multiple instrument calibrations and calibration setups. Field technicians can now perform a broadband calibration and change the frequency range after calibration without having to recalibrate the instrument. A zoom-in/zoom-out capability is available in Return Loss, Cable Loss or VSWR mode. Because the resolution and maximum distance are dependent on the frequency range, field technicians can even change the frequency range in DTF mode to produce the desired fault resolution and horizontal range needed for the measurement, without performing additional calibrations.

# InstaCal<sup>™</sup> Calibration

The InstaCal Calibration module is available in the S331D and S332D and users can cut the time required to calibrate the Site Master by as much as 50 percent. With InstaCal, users are only required to connect the InstaCal calibration module once and the calibration process will be done automatically.



# **RF** Immunity

In today's wireless environment it is very common that there will be other RF activity present when making a measurement. In order to make accurate measurements in hostile RF environments, the receiver has to be able to reject the unwanted signals. Special dithering techniques are applied to the Site Master when making a measurement, and the Site Master can reject signals up to +17 dBm ensuring accurate measurements in RF rich environments.

# **Optical Distance-To-Fault**

The ODTF-1 accessory module can be used with Anritsu's handheld cable & antenna analyzers to make high resolution Optical DTF (Distance-To-Fault) measurements.

The combination of the Site Master and ODTF-1 module provides users with an efficient solution for characterizing both RF and Fiber Optic systems such as Remote Radio Head configured BTS systems.






The Site Master S332D integrated Spectrum Analysis capability provides the "ultimate" in measurement flexibility for field environments and applications requiring mobility. With the S332D you can locate, identify, record and solve communication systems problems quickly and easily, and with incredible accuracy – making it a perfect solution for conducting field measurements in the 100 kHz to 3 GHz frequency range.

# Smart Measurements

The S332D has dedicated routines for measurements of field strength, channel power, occupied bandwidth, Adjacent Channel Power Ratio (ACPR), Carrier-to-Interference, and interference analysis. These are increasingly critical measurements for today's wireless communication systems. The simple interface for these complex measurements significantly reduces test time and increases analyzer usability.



# Occupied Bandwidth

This measurement calculates the bandwidth containing the total integrated power occupied in a given signal bandwidth. There are two different methods of calculation depending on the technique used to modulate the carrier. The user can specify percent of power or the "x" dB down point, where "x" can be from 1 dB to 120 dB below the carrier.

# Adjacent Channel Power Ratio

A common transmitter measurement is that of adjacent channel leakage power. This is the ratio of the amount of leakage power in an adjacent channel to the total transmitted power in the main channel. This measurement is used to replace the traditional two-tone intermodulation distortion (IMD) test for system non-linear behavior.

The result of an ACPR measurement can be expressed either as a power ratio or a power density. In order to calculate the upper and lower adjacent channel values, the S332D allow the adjustment of four parameters to meet specific measurement needs: main channel center frequency, measurement channel bandwidth, adjacent channel bandwidth and channel spacing.

# AM/FM/SSB Demodulator

A built-in demodulator for AM, narrowband FM, wideband FM and single sideband (selectable USB and LSB) allow a technician to easily identify interfering signals.


# 6 GHz Frequency Extension

The FCN4760 is a block down converter for the 4.7 to 6.0 GHz frequency range. It is designed to work with an Anritsu Site Master S332D equipped with Option 6.

This converter is primarily intended for field use by fixed wireless engineers who are responsible for the design, deployment and optimization of 802.11a networks. It is also used to conduct interference analysis measurements to determine the level of interference and locate the sources of interference.

# Frequency Converter Control Module Interface (Option 6, S332D)

Connector providing internal control signals to work with the FCN4760, a block down converter designed for the 4.7 to 6 GHz frequency ranges.





# Power Monitor (Option 5, S331D/S332D)

Use Anritsu's 560 and 5400 series detector to measure broadband power. They are an excellent solution to measure an 18 GHz microwave link carrying the Base Station T1/E1 link. The detectors use precision high return loss detectors with excellent impedance match designed to minimize mismatch uncertainty (See uncertainty curves on page 11). Measurement range is from -50 to +16 dBm and the display range is from -80 to +80 dBm. There are several detectors available designed for different frequency ranges.




( <b>111</b> )	
External Power Sensor	Running Averages
Power	Max
5.53d	Bm
	Limit ON/OFF
PASS	Lower
3.58n	
2.201	IVV Upper Limit
Hold	
Freq:1900.00 MHz Offset:Off Relative:Off Max Hold:Off Zero Adj:On Averages:Off	Limits:On Up Limit:5.70 dBm Lo Limit:5.40 dBm

## High Accuracy Power Meter (Option 19, S331D/S332D)


Anritsu's PSN50 sensor makes high accuracy power measurement from 50 MHz to 6 GHz. The sensor provides true RMS measurements from –30 to +20 dBm enabling users to make accurate measurements for CW and digitally modulated signals such as CDMA/EV-DO, GSM/EDGE, and WCDMA/HSDPA. The sensor is equipped with an RS-232 interface for fast and easy connection to the Site Master. Power is displayed in both dBm and Watts. Upper and lower

limits can be turned on for Pass/Fail measurements.



# Power Meter (Option 29, S331D/S332D)

The power meter tool performs accurate transmitter power meter measurements from 3 MHz to 3 GHz reducing coverage holes and interference. The Spectrum Analyzer is used to measure the channel power and results can be displayed in dBm or Watts. No external detector is required.




## Channel Scanner (Option 27, S332D)

The Channel Scanner option measures the power of multiple transmitted signals, and is very useful for measuring the channel power of AMPS, iDEN, GSM, CDMA/EV-DO, and TDMA networks.

# Built-in Bias Tee (Option 10A, S332D)

Built-in power supply can be turned on as needed to place +12 to +24V (variable in 1V steps) on the center conductor of the RF In port. It is designed to deliver 6W steady state.



## Transmission Measurement (Option 21, S332D)

Built-in signal source from 25 MHz to 3 GHz provides the capability to make 2-port measurements and measure gain, loss, or isolation of devices such as filters, cables, attenuators, amplifiers, and antennas.

# Interference Analyzer (Option 25, S332D)

The interference analyzer option displays interference in four different ways: Spectrogram, RSSI, Signal Strength, Signal ID.

## Spectrogram


The Site Master Spectrogram is a three dimensional display of frequency, power and time of the spectrum activity to identify intermittent interference and track signal levels over time. The Site Master can save a history up to three days.


## RSSI

RSSI measurement is useful to observe the signal strength of a single frequency over time. The data can be collected for up to seven days.

## Locating an Interfering Signal

Connect a directional antenna to the Site Master and locate the interfering source by measuring the strength of the interfering signal. Signal strength is indicated as an audible beep.





# CW Signal (Option 28, S332D)

Provides a CW signal from -6 dBm to -80 dBm in 1 dB step from 25 MHz to 2 GHz. The attenuator connected to the RF port can be varied from 0 to 90 dB in 1 dB steps and the splitter divides the signal into two signals: One is fed into the device under test and one is fed into the Spectrum Analyzer Receiver port. The display shows the output power and the frequency. The CW Signal mode and the Power Monitor mode can be operated simultaneously in units with both options installed providing the user with the flexibility to send out and monitor a signal at the same time.






# GPS Receiver (Option 31, S331D/S332D)

Built-in GPS provides location information (latitude, longitude, and altitude) and Universal Time (UT) information. Site Master can stamp each trace with location information to check if the measurements are taken at the right location. Site Master stores the GPS location information until the unit is turned off. This stored location information can be used to stamp traces taken indoors at the same cell site location. The GPS option is offered with a magnet mount antenna

with a 15-foot (~ 5m) cable to mount on the car or other useful surface.

# T1/E1 Analyzer (Option 50, S331D)

Site Master built-in T1/E1 Analyzer performs T1/E1 functional tests, simplifying the task of determining if the source of the problem is on the wireline or the wireless side. Site Master can display the T1/E1 data in histogram form and collect the data for up to two days. Site Master can also measure the voltage (Vpp) of the signal and it can also be displayed as dBdsx.



Master Software Tools provides the user with comprehensive data management and post processing tools which augment the capabilities of the Site Master. This software provides a simple and easy way to manage, archive, analyze, print measurement reports, customize your cable list, antenna list, signal standards list and keep your Site Master up to date with the latest instrument firmware. Master Software Tools (MST) is a Windows program which is included with every Site Master instrument. For the most current version of Master Software Tools, please visit www.us.anritsu.com.




Figure 1, DTF trace transferred to MST

- Up to 300 Site Master trace memory locations can be downloaded with a single menu selection
- · Build historical records with an unlimited number of traces in one document
- Intelligent Trace Renaming features allow you to rename hundreds of traces in minutes instead of hours.
- Edit and create custom signal standards and cable lists
- Create custom reports
- View Spectrogram displays in 3D
- Copy markers and limit lines from one trace to all the traces in a specific folder with easy to use group edit functions
- Use the Product Update feature to make sure you always use the latest instrument firmware.

	fer CVMSTText,2				D
Vanana	Time Starg		Subtle		Help & Instructio
45 vna	425/2008 12:57.33	Morgan Hill Alpha Red Antenna			
EVNA.	425/2008 10 07 38	Morgan Hill Alpha Red Antenna			
IVTOA.	425/2008 12 57.44	Morgan Hill Alpha Red Antenna			
21714	5/6/2008 3 46 05 PM	Morgan Hill Alpha Flad Antains			
CUTUA.	4262888133884	Morgan Hill Alpha Red Antenna			
VTMA.	4242000102840.	Morgan Hill Alpha Red Antenna			
SYSA	428/2008 318 31 PM	Morgon Hill Alpha Fled Antenno			
plured \rbiA	6/27/2000 9 34 08 AM				
E SYNA		Morgan Hill Alpha Red Anteres			
10 VINA	\$V\$2008 11.02.41 AM	Morgan Hill Alpha. Red Avlance			
ZVNA		Morgan Hill Alpha Fled Artenna			and the second se
2VNA SVNA		Morgan Hill Alpha Red Antenna Morgan Hill Alpha Red Antenna			
SVIDA	1/1/2008 11/01 25 AM	Morgen Hill Alpha Red Antenna Morgen Hill Alpha Red Antenna			
ZUNA		Morgan Hill Alpha Faed Anteren			
E'VTUA		Morgan Hill Alpha Rad Antanna			
SUTUR	E-B-0006 11 02 15 444	Morges Hill Alpha Red America			
AVIA	78000592325444	Morgan Hill Alpha Fled Antenna			
I.VNA.	403000834518754	Morpen Hill Alpha Field Antenna			
21/194	4/23/2008 2:57 60 PM	Morgan Hill Alpha, Fland Antenna			
2VTMA		Morgan Hill Alpha Red Antenna			
4'1764	4/28/2008 2:51 31 PM	Morgan Hill Alpha Red Antenna			
		ise enveloped weather enveloped terreit.			
9 Fed1	E for	Z Fell3	C Peed	· ·	late S
					ena 2
× Morganitil	100	P 14	1 C (1)	1. (R)	
0				and in the local division of the local divis	
<u></u>				A Loss Arthurs	S
111	100	and the second se			
e.	P	P	- C -	* 12ml	
			C 17	C.	
-					
2	- 21		-	and the second s	

Figure 2, Update file names with the Trace Rename utility




Figure 3, View Spectrogram displays in 3D

# Specifications

#### Cable and Antenna Analyzer (S331D/S332D)

Frequency Range: 25 MHz to 4.0 GHz Frequency Accuracy: ≤ ±50 ppm @ +25° C Frequency Resolution: 1 kHz (CW On) 100 kHz (CW Óff) Output Power: <0 dBm (-10 dBm nominal) Immunity to Interfering Signals: On-channel: +17 dBm On-frequency: -5 dBm Measurement Speed: ≤2.5 msec / data point (CW ON) Number of Data Points: 130, 259, 517 Return Loss: Range: 0.00 to 60.00 dB Resolution: 0.01 dB VSWR: Range: 1.00 to 65.00 Resolution: 0.01 Cable Loss: Range: 0.00 to 30.00 dB Resolution: 0.01 dB Measurement Accuracy: >42 dB corrected directivity after calibration Distance-to-Fault: Vertical Range: Return Loss: 0.00 to 60.00 dB VSWR 1.00 to 65.00 Horizontal Range: 0 to (# of data pts -1) x Resolution to a maximum of 1497m (4912 ft), # of data pts = 130, 259 or 517 Horizontal Resolution (Rectangular Windowing)

Resolution (meter) =  $(1.5 \times 10^{\circ}) \times (Vp)/DF$ Where Vp is the cable's relative propagation velocity and where DF is the stop frequency minus the start frequency (in Hz).

#### Spectrum Analyzer (S332D)

#### Frequency:

Frequency Range: 100 kHz to 3.0 GHz (tunable to 9 kHz) Frequency Reference (Internal Timebase) Aging: ±1 ppm/yr Accuracy: ±2 ppm Frequency Span: 10 Hz to 2.99 GHz in 1, 2, and 5 step selections in auto mode, plus zero span Sweep Time: ≤1.1 sec full span ≤50 µsec to 20 sec selectable in zero span Resolution Bandwidth (-3 dB): 100 Hz to 1 MHz in 1-3 sequence ±5% Accuracy Video Bandwidth (-3 dB): 3 Hz to 1 MHz in 1-3 sequence ±5% Accuracy typical SSB Phase Noise (1 GHz) @ 30 kHz Offset: ≤-75 dBc/Hz Spurious Responses Input Related: ≤-45 dBc Spurious Residual Responses: -90 dBm, ≥10 MHz –80 dBm. <10 MHz (10 kHz RBW, pre-amp on)

#### Amplitude:

Total Level Accuracy: ±1 dB typical (±1.5 dBm max), ≤10 MHz to 3 GHz ±2 dB typical, <10 MHz for input signal levels ≥-60 dBm, excludes input VSWR mismatch Measurement Range: +20 dBm to -135 dBm Input Attenuator Range: 0 to 51 dB, selected manually or automatically coupled to the reference level. Resolution in 1 dB steps Displayed Average Noise Level: ≤--135 dBm, ≥10 MHz (preamp on) ≤-115 dBm, <10 MHz (preamp on) for input terminated, 0 dB attenuation, RMS detection, 100 Hz RBW Dynamic Range: >65 dB, typical Display Range: 1 to 15 dB/division, in 1 dB steps, 10 divisions displayed Scale Units: dBm, dBV, dBmV, dBmV, V, W RF Input VSWR: (with ≥ 20 dB atten.), 1.5:1 typical, (10 MHz to 2.4 GHz) 2 MHz Frequency Extension (Option 2 S331D/S332D) Cable & antenna frequency range: 2 MHz to 4000 MHz (All other specs remain the same as standard S33xD) 6 GHz Frequency Extension (Option 16 S331D/S332D) Cable & antenna frequency range: 25 MHz to 6000 MHz (All other specs remain the same as standard S33xD) Power Monitor (Option 5 S331D/S332D) Detector Range: -80 to +80 dBm (10 pW to 100 kW Measurement Range: -50 to +16 dBm (10 nW to 40 mW) Offset Range: 0 to +60 dB Resolution: 0.1 dB. 0.1W Accuracy: ± 1 dB

#### Bias Tee (Option 10A S332D)

Voltage: +12V to +24V (variable in 1V steps) Power: 6W steady state Current: 6W/Voltage (V) High Accuracy Power Meter PSN50

#### (Option 19 S331D/S332D) Sensor:

Measurement Range: -30 to +20 dBm Frequency Range: 50 MHz to 6 GHz Input Connector: Type N, male, 50 Ω Max Input without Damage: +33 dBm,  $\pm 25$  VDC Input Return Loss: 50 MHz to 2 GHz: ≥26 dB 2 GHz to 6 GHz: ≥20 dB

#### Accuracy:

Total RSS Measurement Uncertainty (0 to 50° C): ±0.16 dB\* Noise: 20 nW max Zero Set: 20 nW Zero Drift: 10 nW max\*\* Sensor Linearity: ±0.13 dB max Instrumentation Accuracy: 0.00 dB Sensor Cal Factor Uncertainty: ±0.06 dB Temperature Compression: ±0.06 dB max Continuous Digital Modulation Uncertainty: +0.06 dB (+17 to +20 dBm) \*Excludes noise, zero set, zero drift for levels <-20 dBm. Excludes noigital modulation uncertainty between +17 and +20 dBm. \*After 30 minute warm-up

#### System:

Measurement Resolution: 0.01 dB Offset Range: ±60 dB

#### Power Requirements:

Supply Voltage: 8 to 18 Vdc Supply Current: <100 mA Transmission Measurement (Option 21 S332D)

Frequency Range: 25 MHz to 3.0 GHz Frequency Resolution: 10 Hz Output Power Level: -10 dBm typical Dynamic Range: 80 dB, 25 MHz to 2 GHz 60 dB, >2 GHz to 3 GHz Output Impedence: 50 Ω

Channel Scanner (Option 27 S332D)

Frequency Range: 100 kHz to 3.0 GHz

Frequency Accuracy: ±10 Hz + Time base error, 99% confidence level

Measurement Range: +20 dBm to -100 dBm Channel Power: ±1 dB typical (±1.5 dB max)

Adjacent Channel Power Accuracy: ±0.75 dBc

Power Meter (Option 29 S331D/S332D) Frequency Range: 3 MHz to 3.0 GHz

Measurement Range: -80 dBm to +20 dBm (+80 dBm with 60 dB external attenuator)

Display Range: -80 dBm to +80 dBm Offset Range: 0 to +60 dB

Accuracy\*\*\*:  $\pm 1$  dB typical ( $\pm 1.5$  dBm max), >2 GHz to 3 GHz  $\pm 2$  dB typical, 3 MHz to <10 MHz

VSWR: 1.5:1 typical (P<sub>in</sub> >–30 dBm, 10 MHz to 2.4 GHz) Maximum Power: +20 dBm (0.1W) without external attenuator \*\*\*(Excludes Input VSWR)

GPS (Option 31 S331D/S332D)


GPS Location Indicator Latitude, Longitude, and Altitude on Display Latitude. Longitude. and Altitude with trace storage

T1 Analyzer (Option 50 S331D) Line Coding: AMI, B8ZS Framing Modes: D4 (Superframe) ESF (Extended Superframe) Connection Configurations: Terminate (100 Ω) Bridge (≥1000 Ω) Monitor (Connect via 20 dB pad in DSX) Receiver Sensitivity: 0 to –36 dBdsx Transmit Level: 0 dB, –7.5 dB, and –15 dB Clock Sources: External Internal 1.544 MHz ±30 ppm Pulse Shapes: Conform to ANSI T1.403


Inverted and non-inverted, QRSS, 1-in-8 (1-in-7), 2-in-8, 3-in-24, All ones, All zeros, T1-Daly, User defined (≤32 bits) Circuit Status Reports: Carrier present, Frame ID and Sync, Pattern ID and Sync Alarm Detection: AIS (Blue Alarm), RAI (Yellow Alarm) Error Detection: Frame Bits, Bit, BER, BPV, CRC, Error Sec Error Insertion: Bit, BPV, Framing Bits, RAI, AIS Loopback Modes: Self loop, CSU, NIU, User defined, In-band or Data Link Level Measurements: Vp-p (± 5%) Data Log: Continuous, up to 48 hrs E1 Analyzer (Option 50 S331D) Line Coding: AML HDB3 Framing Modes: PCM30, PCM30CRC, PCM31, PCM31CRC Connection Configurations: Terminate (75 Q, 120 Q) Bridge (≥1000 Ω) Monitor (Connect via 20 dB pad in DSX) Receiver Sensitivity: 0 to -43 dB Transmit Level: 0 dB, -7.5 dB, and -15 dB Clock Sources: External Internal 2.048 MHz ±30 ppm Pulse Shapes: Conform to ITU G.703 Pattern Generation and Detection: PRBS: 2-9, 2-11, 2-15, 2-20, 2-23 Inverted and non-inverted, QRSS, 1-in-8 (1-in-7), 2-in-8, 3-in-24, All ones, All zeros, T1-Daly, User defined (≤32 bits) Circuit Status Reports: Carrier present, Frame ID and Sync, Pattern ID and Svnc Alarm Detection: AIS, RAI, MMF Error Detection: Frame Bits, Bit, BER, BPV, CRC, E-Bits, Error Sec Error Insertion: Bit, BPV, Framing Bits, RAI, AIS Loopback Modes: Self loopback Level Measurements: Vp-p (±5%) Data Log: Continuous, up to 48 hrs General Language Support: Chinese, English, French, German, Japanese, Spanish Internal Trace Memory: 300 traces Setup Configuration: S332D - 25, S331D - 10 Display: TFT color LCD with adjustable backlight Inputs and Outputs Ports RF Out: Type N, female, 50 Q Maximum Input without Damage: +23 dBm, ±50 VDC RF In: Type N, female, 50 Ω Maximum Input without Damage: +43 dBm (peak), ±50 VDC Ext. Trig In: BNC, female (5V TTL) (S332D Models only) Ext. Freq Ref In (2 to 20 MHz): Shared BNC, female, 50 O (-15 dBm to +10 dBm) (S332D Models only) T1/E1 (Receive and Transmit): Bantam Jack (S331D Models with Option 50 only) Serial Interface: RS-232 9 pin D-sub, three wire serial Electromagnetic Compatibility: Meets European Community requirements for CE marking Safety: Conforms to EN 61010-1 for Class 1 portable equipment Temperature: Operating: -10° C to 55° C, humidity 85% or less Non-operating: -51° C to +71° C (Recommend the battery be stored separately between 0° C and +40° C for any prolonged non-operating storage period.) Environmental: MIL-PRF-28800F Class 2 Power Supply: External DC Input: +12.5 to +15 volt dc, 3A max Internal NiMH battery: 10.8 volts, 1800 mAH Dimensions: Size (w x h x d): 254 mm x 178 mm x 61 mm (10.0 in x 7.0 in x 2.4 in) Weight: <2.28 kg (<5 lbs) includes battery

Pattern Generation and Detection: PRBS: 2-9, 2-11, 2-15, 2-20, 2-23

The following graphs provide measurement uncertainty accuracy at  $23^{\circ} \pm 3^{\circ}$  C after vector error correction for the standard N connector types. The errors are worst-case contributions of residual directivity, source match, frequency response, network analyzer dynamic range, and connector repeatability. In preparing these graphs, Fixed CW is ON. Calibration components 22N50 and 28N50-2 are used.



Using the 560-7N50B detector, the following curves show estimated power monitor uncertainties for various DUT match.



Estimated Power Monitor Uncertainty for Three DUT Match Levels at 18 GHz

Estimated Power Monitor Uncertainty for Three Frequencies at –30 dB Match

# Power Monitor - Detectors

Model	Frequency Range	Impedance	Return Loss	Input Connector	Frequency Response
5400-71N50	0.001 to 3 GHz	50 Ω	26 dB	N(m)	±0.2 dB, <1 GHz ±0.3 dB, <3 GHz
5400-71N75	0.001 to 3 GHz	75 Ω	26 dB, <2 GHz 20 dB, <3 GHz	N(m)	±0.2 dB, <1 GHz ±0.5 dB, <3 GHz
560-7N50B	0.01 to 20 GHz	50 Ω	15 dB, <0.04 GHz 22 dB, <8 GHz 17 dB, <18 GHz 14 dB, <20 GHz	N(m)	±0.5 dB, <18 GHz ±1.25 dB, <20 GHz
560-7S50B	0.01 to 20 GHz	50 Ω	15 dB, <0.04 GHz 22 dB, <8 GHz 17 dB, <18 GHz 14 dB, <20 GHz	WSMA(m)	±0.5 dB, <18 GHz ±1.25 dB, <20 GHz
560-7K50	0.01 to 40 GHz	50 Ω	12 dB, <0.04 GHz 22 dB, <8 GHz 17 dB, <18 GHz 15 dB, <26.5 GHz 14 dB, <32 GHz 13 dB, <40 GHz	K(m)	±0.5 dB, <18 GHz ±1.25 dB, <26.5 GHz ±2.2 dB, <32 GHz ±2.5 dB, <40 GHz
560-7VA50	0.01 to 50 GHz	50 Ω	12 dB, <0.04 GHz 19 dB, <20 GHz 15 dB, <40 GHz 10 dB, <50 GHz	V(m)	±0.8 dB, <20 GHz ±2.5 dB, <40 GHz ±3.0 dB, <50 GHz

# **Ordering Information**

## Basic Models

Basic Models	
S331D	Cable and Antenna Analyzer (25 MHz to 4.0 GHz)
S332D	Cable and Antenna Analyzer (25 MHz to 4.0 GHz), Spectrum Analyzer (100 kHz to 3.0 GHz)
Outline	
Options	
Option 2	2 MHz frequency extension (S331D/S332D)
Option 5	Power Monitor - requires external detector (S331D/S332D)
Option 6	Frequency Converter Control Module Interface - can not be ordered with Option 5 (S332D)
Option 10A	+12 to +24V Variable (1V steps) Bias Tee (S332D)
Option 16	6 GHz frequency extension,
	Cable & Antenna Analyzer (S331D/S332D)
Option 19	High Accuracy Power Meter (S331D/S332D)
	(PSN50 sensor not included)
Option 21	Transmission Measurement (S332D)
Option 25	Interference Analyzer - requires color display
	and requires directional antenna (S332D)
Option 27	Channel Scanner (S332D)
Option 28	CW Signal Generator - requires
	CW Signal Generator Kit (S332D)
Option 29	Power Meter - does not require
	external detector (S331D/S332D)
Option 31	GPS Receiver for location information.
0 // 50	Includes GPS antenna (S331D/S332D)
Option 50	T1/E1 Analyzer - can not be ordered with
	Option 5 (S331D)
Standard Accessories	3
10580-00079	S331D/S332D Site Master User's Guide
2300-347	Anritsu Handheld Software Tools CDROM
65717	Soft Carrying Case
633-27	Rechargeable Battery, NiMH
40-168-R	AC-DC Adapter with Power Cord
551-1691-R	USB to RS-232 adapter cable
806-141	Automotive Cigarette Lighter/12 Volt DC Adapter
800-441	Serial Interface Cable
	One Year Warranty
<b>Optional Accessories</b>	
FCN4760	Frequency Converter, 4.7 GHz to 6 GHz
1N50C	Limiter, N(m) to N(f), 50 Ω, 10 MHz to 18 GHz
65701	Offset Cal Kit consisting of one each:
	3-1010-119, 10 dB Attenuator, DC to 6 GHz 2W
	3-806-151, 4 GHz Cable, 18 in. (46 cm)
ODTF-1	Optical DTF Module
2000-1410	Magnet mount GPS antenna with 15 ft. cable
61534	CW Signal Generator Kit with variable step attenuator
551-1691-R	USB to RS-232 adapter cable

Soft Carrying Case

Site Master Backpack Rechargeable Batter, NiMH

Serial Interface Cable

Bantam Plug to Bantam Plug Bantam Plug to BNC

Bantam "Y" Plug to RJ48

Battery Charger, NiMH, with Universal Power Supply

Automotive Cigarette Lighter/12Volts DC Adapter

Transit Case

AC/DC Adapter

Software Tools

#### **Calibration Components**

ICN50	InstaCal™ Calibration Module,
22N50	25 MHz to 4.0 GHz, N(m), 50 Ω Open/Short, DC to 18 GHz, N(m), 50 Ω
22NF50	Open/Short, DC to 18 GHz, N(f), 50 Ω
SM/PL-1	Precision Load, DC to 6 GHz, 42 dB, N(m), 50 $\Omega$
SM/PLNF-1	Precision Load, DC to 6 GHz, 42 dB, N(f), 50 Ω
OSLN50-1	Precision Open/Short/Load, DC to 6 GHz, 42 dB,
OSLNF50-1	50 Ω, N(m) Precision Open/Short/Load, DC to 6 GHz, 42 dB,
USLINI JU-1	50 $\Omega$ , N(f)
2000-767	Precision Open/Short/Load, DC to 4 GHz,
2000 . 0.	7/16 DIN(m), 50 Ω
2000-768	Precision Open/Short/Load, DC to 4 GHz,
	7/16 DIN(f), 50 Ω
22N75	Open/Short, DC to 3 GHz, N(m) 75 Ω
22NF75	Open/Short, DC to 3 GHz, N(f) 75 Ω
26N75A	Precision Termination, DC to 3 GHz, N(m) 75 $\Omega$
26NF75A	Precision Termination, DC to 3 GHz, N(f) 75 Ω
12N50-75B	Matching Pad, DC to 3 GHz, 50 $\Omega$ to 75 $\Omega$
Adapters	
•	Draginian Adapter N(m) N(m) DO to 40 OU 50 O
34NN50A	Precision Adapter, N(m)-N(m), DC to 18 GHz, 50 $\Omega$
34NFNF50	Precision Adapter, N(f)-N(f), DC to 18 GHz, 50 $\Omega$
1091-26-R	Adapter, N(m)-SMA(m), DC to 18 GHz, 50 Ω
1091-27-R	Adapter, N(m)-SMA(f), DC to 18 GHz, 50 Ω
1091-80-R	Adapter, N(f)-SMA(m), DC to 18 GHz, 50 $\Omega$
1091-81-R	Adapter, N(f)-SMA(f), DC to 18 GHz, 50 $\Omega$
1091-172	Adapter, N(m)-BNC(f), DC to 1.3 GHz, 50 $\Omega$
510-90-R	Adapter, 7/16 DIN(f)-N(m), DC to 7.5 GHz, 50 $\Omega$
510-91-R	Adapter, 7/16 DIN(f)-N(f), DC to 7.5 GHz, 50 $\Omega$
510-92-R	Adapter, 7/16 DIN(m)-N(m), DC to 7.5 GHz, 50 $\Omega$
510-93-R	Adapter, 7/16 DIN(m)-N(f), DC to 7.5 GHz, 50 $\Omega$
510-96-R	Adapter, 7/16 DIN(m)-7/16 DIN (m), DC to 7.5 GHz, 50 C
510-97-R	Adapter, 7/16 DIN(f)-7/16 DIN(f), DC to 7.5 GHz, 50 Ω
Test Port Cables	
3-806-151	Cable, 0.46m, N(m)-N(m), 4 GHz, 50 Ω
806-186-R	Cable, 0.91m, N(m)-N(f), 4 GHz, 50 Ω
806-187-R	Cable, 0.91m, N(m)-N(f), 4 GHz, 50 Ω
Test Port Cable Ar	mored
15NN50-1.5C	Test Port Cable Armored, 1.5 meters,
	N(m)-N(m), 6 GHz, 50 $\Omega$
15NN50-3.0C	Test Port Cable Armored, 3.0 meters,
	N(m)-N(m), 6 GHz, 50 Ω
15NN50-5.0C	Test Port Cable Armored, 5.0 meters,
	N(m)-N(m), 6 GHz, 50 Ω
15NNF50-1.5C	Test Port Cable Armored, 1.5 meters,
	N(m)-N(f), 6 GHz, 50 Ω
15NNF50-3.0C	Test Port Cable Armored, 3.0 meters,
	N(m)-N(f), 6 GHz, 50 Ω
15NNF50-5.0C	Test Port Cable Armored, 5.0 meters,
	N(m)-N(f), 6 GHz, 50 Ω
15ND50-1.5C	Test Port Cable Armored, 1.5 meters,
	N(m)-7/16 DIN(m), 6 GHz, 50 $\Omega$
15NDF50-1.5C	Test Port Cable Armored, 5.0 meters, N(m)-7/16 DIN(f)), 6 GHz, 50 $\Omega$
	אוט טו <i>וו-וו</i> וויט טו און וויט סו גען אווט אוויט און אוויט
Test Port Cable Ar	mored w/ Reinforced Grip
15RNFN50-1.5-R	Test Port Cable Armored w/ Reinforced Grip,

15RNFN50-1.5-R	Test Port Cable Armored w/ Reinford
	1.5 meters, N(m)-N(f), 6 GHz, 50 $\Omega$

65717

67135

633-27

760-243-R

2000-1029

40-168-R

806-141 800-441

806-16

806-116 806-117

2300-347

### **Portable Antennas**

2000-1030 SMA(m), 1.71 to 1.88 GHz, 50 Ω	
2000-1031 SMA(m), 1.85 to 1.99 GHz, 50 Ω	
2000-1032 SMA(m), 2.4 to 2.4835 GHz, 50 Ω	
2000-1035 SMA(m), 896 to 941 MHz, 50 Ω	
2000-1361 SMA(m), 5725 to 5825 MHz, 50 Ω	
2000-1200 SMA(m), 806 to 866 MHz, 50 Ω	
2000-1473 SMA(m), 870 to 960 MHz, 50 Ω	
2000-1474 SMA(m), 1.71 to 1.88 GHz, 50 Ω	
2000-1475 SMA(m), 1920 to 1980, 2110 to 217	0 MHz, 50 Ω

### 61532 Antenna Kit:

2000-1030, 2000-1031, 2000-1032, 2000-1035, 2000-1200, and 2000-1361

#### **Directional Antennas**

2000-1411	Portable Yagi Antenna, 10 dBd, N(f), 822 to 900 MHz
2000-1412	Portable Yagi Antenna, 10 dBd, N(f), 885 to 975 MHz
2000-1413	Portable Yagi Antenna, 10 dBd, N(f), 1710 to 1880 MHz
2000-1414	Portable Yagi Antenna, 9.3 dBd, N(f), 1850 to 1990 MHz
2000-1415	Portable Yagi Antenna, 12 dBd, N(f), 2400 to 2500 MHz
2000-1416	Portable Yagi Antenna, 12 dBd, N(f), 1920 to 2170 MHz

#### **Band Pass Filters**

1030-105-R	890 to 915 MHz, N(m)-N(f), 50 Ω
1030-106-R	1710 to 1790 MHz, N(m)-N(f), 50 Ω
1030-107-R	1910 to 1990 MHz, N(m)-N(f), 50 Ω
1030-109-R	824 to 849 MHz, N(m)-N(f), 50 Ω
1030-110-R	880-915 MHz, N(m)-SMA(f), 50 Ω
1030-111-R	1850-1910 MHz, N(m)-SMA(f), 50 Ω
1030-112-R	2400-2484 MHz, N(m)-SMA(f), 50 Ω
1030-114-R	806-869 MHz, N(m)-SMA(f), 50 Ω

### High Accuracy Power Meter Accessories

PSN50 40-168-R 800-441 65701	High Accuracy Power Sensor, 50 MHz to 6 GHz AC-DC Adapter Serial Interface Cable 3 GHz Offset Cal Kit consisting of one each: 3-1010-119, 10 dB Attenuator, DC to 6 GHz, 2W 3-806-151, 4 GHz Cable, 18" (46 cm)
Attenuators	
42N50-20 42N50A-30 1010-121 1010-127-R 1010-128-R 3-1010-122 3-1010-123 3-1010-124	Attenuator, 20 dB, 5W, DC to 18 GHz, N(m)-N(f) Attenuator, 30 dB, 50W, DC to 18 GHz, N(m)-N(f) Attenuator, 40 dB, 100W, DC to 18 GHz, N(m)-N(f) Attenuator, 30 dB, 150W, DC to 3 GHz, N(m)-N(f) Attenuator, 40 dB, 150W, DC to 3 GHz, N(m)-N(f) Attenuator, 20 dB, 5W, DC to 12.4 GHz, N(m)-N(f) Attenuator, 30 dB, 50W, DC to 8.5 GHz, N(m)-N(f) Attenuator, 40 dB, 100W, DC to 8.5 GHz, N(m)-N(f), Uni-directional

## **Product Literature**

10580-00079	
10580-00100	

S331D/S332D Site Master User's Guide S331D/S332D Site Master Programming Guide

# /Inritsu

Anritsu Corporation 5-1-1 Onna, Atsugi-shi, Kanagawa, 243-8555 Japan Phone: +81-46-223-1111 Fax: +81-46-296-1264

• U.S.A. Anritsu Company 1155 East Collins Boulevard, Suite 100, Richardson, Texas 75081 U.S.A. Toll Free: 1-800-ANRITSU (267-4878) Phone: +1-972-644-1777 Fax: +1-972-671-1877 Canada

Anritsu Electronics Ltd. 700 Silver Seven Road, Suite 120, Kanata, Ontario K2V 1C3, Canada Phone: +1-613-591-2003 Fax: +1-613-591-1006

• Brazil Anritsu Electrônica Ltda. Praca Amadeu Amaral 27-1 Andar 01327-010 - Paraiso, São Paulo, Brazil Phone: +55-11-3283-2511 Fax: +55-11-3886940

Mexico

Anritsu Company, S.A. de C.V. Av. Ejército Nacional No. 579 Piso 9, Col. Granada 11520 México, D.F., México Phone: +52-55-1101-2370 Fax: +52-55-5254-3147

• U.K.

Anritsu EMEA Ltd. 200 Capability Green, Luton, Bedfordshire LU1 3LU, U.K. Phone: +44-1582-433280 Fax: +44-1582-731303

France

Anritsu S.A.

16/18 Avenue du Québec-SILIC 720 91961 COURTABOEUF CEDEX, France Phone: +33-1-60-92-15-50 Fax: +33-1-64-46-10-65

### Germany

Anritsu GmbH Nemetschek Haus, Konrad-Zuse-Platz 1 81829 München, Germany Phone: +49 (0) 89 442308-0 Fax: +49 (0) 89 442308-55

 Italy Anritsu S.p.A. Via Elio Vittorini, 129, 00144 Roma, Italy Phone: +39-06-509-9711 Fax: +39-06-502-2425

 Sweden Anritsu AB Borgafjordsgatan 13, 164 40 Kista, Sweden Phone: +46-8-534-707-00 Fax: +46-8-534-707-30 Finland

#### Anritsu AB Teknobulevardi 3-5, FI-01530 Vantaa, Finland Phone: +358-20-741-8100 Fax: +358-20-741-8111

 Denmark Anritsu A/S Kirkebjerg Allé 90 DK-2605 Brøndby, Denmark Phone: +45-72112200 Fax: +45-72112210

 Spain Anritsu EMEA Ltd. Oficina de Representación en España

Edificio Veganova Avda de la Vega, nº 1 (edf 8, pl1, of 8) 28108 ALCOBENDAS - Madrid, Spain Phone: +34-914905761 Fax: +34-914905762

 Russia Anritsu EMEA Ltd.

Representation Office in Russia Tverskaya str. 16/2, bld. 1, 7th floor. Russia, 125009, Moscow Phone: +7-495-363-1694 Fax: +7-495-935-8962

 United Arab Emirates Anritsu EMEA Ltd. **Dubai Liaison Office** 

P O Box 500413 - Dubai Internet City Al Thuraya Building, Tower 1, Suite 701, 7th Floor Dubai, United Arab Emirates Phone: +971-4-3670352 Fax: +971-4-3688460

Singapore

Anritsu Pte. Ltd. 60 Alexandra Terrace, #02-08, The Comtech (Lobby A) Singapore 118502 Phone: +65-6282-2400 Fax: +65-6282-2533 • India

Anritsu Pte. Ltd.

India Branch Office

3rd Floor, Shri Lakshminarayan Niwas, #2726, HAL 3rd Stage, Bangalore - 560 038, India Phone: +91-80-4058-1300 Fax: +91-80-4058-1301

• P. R. China (Hong Kong)

Anritsu Company Ltd. Units 4 & 5, 28th Floor, Greenfield Tower, Concordia Plaza, No. 1 Science Museum Road, Tsim Sha Tsui East, Kowloon, Hong Kong, P.R. China Phone: +852-2301-4980 Fax: +852-2301-3545

• P. R. China (Beijing)

Anritsu Company Ltd. **Beijing Representative Office** 

Room 1515, Beijing Fortune Building, No. 5, Dong-San-Huan Bei Road, Chao-Yang District, Beijing 100004, P.R. China Phone: +86-10-6590-9230 Fax: +82-10-6590-9235

Korea

Anritsu Corporation, Ltd. 8F Hyunjuk Bldg. 832-41, Yeoksam-Dong, Kangnam-ku, Seoul, 135-080, Korea Phone: +82-2-553-6603 Fax: +82-2-553-6604

Australia

Anritsu Pty Ltd. Unit 21/270 Ferntree Gully Road, Notting Hill Victoria, 3168, Australia Phone: +61-3-9558-8177 Fax: +61-3-9558-8255

Taiwan

Anritsu Company Inc. 7F, No. 316, Sec. 1, Neihu Rd., Taipei 114, Taiwan Phone: +886-2-8751-1816 Fax: +886-2-8751-1817

Please Contact:			

